



Remove your rear coil springs. Hold upper bracket in place and mark hole for air line and all thread.



Drill a hole through the frame for air line and a pilot hole through your trunk floor. Next, drill a 1/2" hole through your frame for your all thread and a pilot hole through your trunk floor.



Going through your trunk floor, drill out an access hole for a socket to reach your frame followed by a smaller hole for your air line.



This is a birds eye view from the the inside of your trunk.



Screw the all thread into the upper bracket and push it through the pre-drilled hole. Mark the all thread just above the top of the frame.



Pull out the all thread and trim it. Run your air line from the bag up through the floor board and then tighten the nut with a socket from your trunk.



Insert grommets as shown for a super clean look.



Install bottom bagel bracket to the air bag.



Now, set the bracket in place!